



## Installation Procedure

### WARNING

1. Switch off before installation.
2. Switch on only after complete installation and examination of the circuit.
3. Professional electrician for installation and maintenance only.




## Downlight



Cutout (refer to cutout table)


Cutout: L80xW80mm/L95xW95mm/L120xW120mm

**1** **2**




Connect power supply

If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.




**3** **4**



COMPLETE

The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.



Model	Cutout
IBSP104SCT080	L80xW80mm
IBSP104SCT080-EB	L80xW80mm
IBSP104SCT080H86	L80xW80mm
IBSP104SCT080H86-EB	L80xW80mm
IBSP104SCT095H78	L95xW95mm
IBSP104SCT095H78-EB	L95xW95mm
IBSP104SCT095H98	L95xW95mm
IBSP104SCT095H98-EB	L95xW95mm
IBSP104SCT095H124	L95xW95mm
IBSP104SCT095H124-EB	L95xW95mm
IBSP104SCT120H125	L120xW120mm
IBSP104SCT120H125-EB	L120xW120mm